



1. Screw the aluminium rail on the vertical tubes.



2. Screw the widest sheet on the vertical tubes.



3. The narrowest sheet would be screwed on the same way on its top and the plastic stops would be added at the end of the tubes.



4. The result of the assembly.



5. Hang the aluminium bracket from the broucher stand, as well from the top as from the bottom.



6. Final assembly.