




Parts

Golf Banner
Ref: 10.426
10.427
10.428



Instructions



The Golf Banner can be assembled in seconds. The system allows a rapid single person set-up. The displays can be folded away quickly and simply and be stored in their own carry bags. The fabric which are self supporting and easily secured is all weather proof and extremely forgiving in all wind conditions.

